

## Universal Remote (UR5L-9000-IP)

**SYSTEM ON/OFF**  
Turn on/off the system.

**MENU**  
Displays applications including the configuration menu.

**GUIDE**  
Opens the Interactive Program Guide.

**ARROW KEYS/OK**  
Navigate on-screen choices.

**SOFT KEYS – YELLOW, BLUE, RED, GREEN**  
Access additional features on your set-top box.

**VOL +/-**  
Raise or lower the volume.

**MUTE**  
Turn the sound off or on.

**FAV**  
View your favorite channels.

**REPLAY**  
Skip backwards while watching a recording or while watching live TV.

**MY DVR**  
Access and manage your recorded programs.

**REWIND**  
Rewind through parts of a recording.

**STOP**  
Press to stop watching a recording or to stop a recording that is in progress.

**PLAY**  
Press to watch a recording or control another device.

**POWER**  
Turn on/off a selected device.

**AUX, DVD, TV, STB**  
Use one remote to control multiple devices.

**INFO**  
Display the current channel and program information.

**EXIT**  
Exit the current screen.

**PAGE +/-**  
Page up or down in menu screens and Interactive Program Guide.

**LAST**  
Recall the last channel you were watching.

**CHANNEL +/-**  
Changes to the next higher or lower channel.

**FAST FORWARD**  
Fast forward through parts of a recording.

**RECORD**  
Press to record a show.

**PAUSE**  
Pause what you are currently watching.

**NUMBER KEYS (0-9)**  
Directly select a channel.

**LIGHT BUTTON**  
Press to backlight all keypad buttons. Press again to turn off (or simply wait 10 seconds for automatic shut-off).

**VIDEO SOURCE**  
In TV control mode, would change the input of the device you are controlling.